



CHAIN SAW - PETROL

70- 43, 46, 47, 48, 49, 50, 51, 52



IMPORTANT:

If you are collecting the equipment for someone else, please make sure this sheet is given to the equipment user to read. If the equipment is being hired for use at a commercial worksite this sheet should be given to the supervisor so that the information is available to all users, as required by the Health and Safety in Employment Act.

SAFETY EQUIPMENT



Ear Muffs



Visor



Helmet



Boots



Chaps



Gloves

Before You Start

- ⇒ Check work area for hazards.
- ⇒ Plan an escape route when tree felling
- ⇒ Ensure you have sufficient fuel.

Do you need

- ♦ safety equipment ?
- ♦ sharpening kit ?
- ♦ fuel ?

General Safety

- ✓ Always use the required safety gear and beware of loose clothing.
- ✓ Do not use in damp or wet conditions.
- ✓ Hold the saw firmly with both hands.
- ✓ Keep your body out of the cutting plane at all times.
- ✓ Don't over-reach or cut above shoulder height.

- ✓ Don't operate near power lines or other electric lines.
- ✓ Don't cut light material such as bamboo or hedges.
- ✓ Don't cut into ground, cable, pipes etc.
- ✓ Keep a slight downward pressure on saw when cutting; release pressure when coming to the end of a cut.
- ✓ Use the spiked bumper against the wood to help steady the saw.

INSTRUCTIONS FOR USE

Starting Procedure

- Engage the chain brake and move the switch to START.
- Cold start - use choke
- Warm start - no choke
- Squeeze throttle trigger and lock with throttle lock.
- Grip handle with left hand and place foot in rear of handle.
- Pull starter cord gently until resistance is felt, then give a short, sharp pull.
- When engine fires, push choke in.
- Once engine is running, release throttle lock by squeezing trigger.
- Disengage chain brake where applicable
- When refuelling, chain oil should also be refilled.
- Use 2-stroke mix and chain oil supplied by Motueka Hire.



Stopping

- Move stop-start switch to STOP.
- Engage chain brake.
- Fit chain protector.

Adjusting Chain Tension

- Stop the chainsaw and adjust the chain tension by loosening the bar securing bolts and tightening the adjusting screw.
- Re-tighten bolts.

397 HIGH STREET
(rear entry HUFFAM STREET)
PHONE: 03 528 7433

Monday - Friday 7:30 - 5:00 Saturday 8:00 - 4:00