



Rotary Tiller



IMPORTANT:

If you are collecting the equipment for someone else, please make sure this sheet is given to the equipment user to read. If the equipment is being hired for use at a commercial worksite this sheet should be given to the supervisor so that the information is available to all users, as required by the Health and Safety in Employment Act.

SAFETY EQUIPMENT



Ear Muffs



Boots



Gloves



Protective Clothing

Before you start

- ⇒ Check the spark plug for proper connection on the spark plug
- ⇒ Check the gas tank is full
- ⇒ Check the oil level
- ⇒ Make certain the clutch is in the dis-engaged position
- ⇒ Read the and understand the operating instructions

- ⇒ Never allow children to operate the Tiller
- ⇒ Keep the area of operation is clear, check for and clear objects like stones, sticks wire etc
- ⇒ Do not refuel fuel tank while the engine is running
- ⇒ Be careful of hot engine parts
- ⇒ Do not make adjustments to the unit while the engine is running.

WHEN OPERATING

- ⇒ Set tilling depth
- ⇒ Engage tine clutch to start tine rotation
- ⇒ Set throttle to comfortable speed
- ⇒ Do not exert pressure or weight on the handle bars (this causes the tines to try to move the digger instead of digging)

Important: Do not overload the digger by trying to till too deep at too fast a rate.

STARTING PROCEEDURE

- ⇒ Move throttle

397 HIGH STREET
(rear entry HUFFAM STREET)
PHONE: 03 528 7433

Monday - Friday 7:30 - 5:00 Saturday 8:00 - 4:00