



## ROTARY TILLER

50.62



## REQUIRED SAFETY EQUIPMENT



Ear Muffs



Gloves



Boots



Protective Clothing

## IMPORTANT:

If you are collecting the equipment for someone else, please make sure this sheet is given to the equipment user to read. If the equipment is being hired for use at a commercial worksite this sheet should be given to the supervisor so that the information is available to all users, as required by the Health and Safety in Employment Act.

## BEFORE YOU START:

- ⇒ Check the oil and fuel are at adequate levels for operation.
- ⇒ Read and understand the operation instructions
- ⇒ Familiarise yourself with the controls
- ⇒ Never allow children to operate.

- ⇒ Clear the ground of objects i.e. stones, wires sticks etc. before starting tilling.
- ⇒ Be careful around hot engine parts.
- ⇒ Stop the engine before refuelling.
- ⇒ Don't make any adjustments to the unit while it is running.
- ⇒ Have the clutch lever in the disengaged position before starting the engine.

## When operating:

- Set tiller depth
- Do not overload the tiller by going too deep too fast.

## Starting Procedure:

- ⇒ Switch on
- ⇒ Move throttle control lever to the center position
- ⇒ Push petrol lever down.
- ⇒ Manually close the choke ( this is not necessary if the engine is warm). Hold the handle with your left hand and pull the starter rope with your right.
- ⇒ Pull the rope with a continuous full arm stroke. Keep a firm grip on the handle don't let the rope snap back against the starter. Repeat until engine starts.
- ⇒ Open choke after engine has started
- ⇒ When the engine warms up move the throttle to the desired position.

## Stopping after Use:

- Move the throttle control to the rear position.
- Switch off.

**397 High Street**  
**(rear entry Huffam street)**  
**Ph: 03 528 7433**

Monday to Friday 7:30-5:00 Saturday 8:00-4:00